



FiberLink® 6656 Series



Visible Fault Locator

Installation and Operations Manual

Contents

| | |
|--------------------------------|---|
| Welcome | 3 |
| Features | 3 |
| Package Contents | 3 |
| Technical Specifications | 4 |
| Functions | 6 |
| Operating Pointers | 7 |
| Troubleshooting | 7 |
| Maintenance and Repairs | 7 |

Welcome

FiberLink 6656 Visible Fault Locator is a light-weight, hand-held tool used to quickly troubleshoot faults in the continuity of both single-mode and multimode fibers, especially at fiber launch points or in OTDR dead zones.

A high-intensity visible red laser beam is precision-coupled into a optical fiber; breaks and micro-bends in the fiber deflect the red light into the fiber jacket, producing a red glow at the point of the fault.

Additionally, the FiberLink 6656 can be used as an end-to-end visual fiber identifier, which is useful for locating fibers terminated in poorly labeled or unlabeled fiber patch panels.

Features

- User selectable output: constant or flashing
- Extended battery life - up to 30 hours on one 9V battery
- Comes equipped with a rugged and durable rubber boot to protect the instrument from drops and other hazards
- Optional ruggedized carrying cases available to accommodate 3 or 6 test devices

Package Contents

- One FiberLink 6656
- This User's Manual
- One Non-Rechargeable Lithium Battery (Pre-installed in unit)

Technical Specifications

| Specifications | |
|-------------------------------|------------------------------|
| Launch Method | Red Laser |
| Connector | 2.5mm universal port |
| Output Power (Approximately): | >2 dBm |
| Visual Range | up to 5km |
| Operating Temperature | 0 - 55° C |
| Power Requirements: | 9 Volt battery |
| Battery Life | Approx. 15 hours |
| Dimensions: | 4.94 x 2.175 x 1.28 (inches) |
| Weight | 10 oz. |



DANGER!

This device emits invisible infrared electromagnetic radiation which can be harmful to human eyes. The radiation from this optical connector, if viewed at close range with no fiber optic cable connected to the optical connector, may be sufficient intensity to cause instantaneous damage to the retina of the eye. Direct viewing of this radiation should be avoided at all times!



1**2.5mm Universal Port:**

This port houses a laser diode that emits visible light into optical fibers either continuously or flashing depending upon the mode selected.

2**3 Position Mode Selector Switch:**

The mode selector switch has three positions from left to right as follows:

Constant (Left): Unit is on, unit will output continuous red laser light

Off (Middle): Unit is off

Flashing (Right): Unit is on, unit will flash red laser light

3**Output Status LED:**

Indicates the unit is in “Constant” or “Flashing” mode and is emitting red laser light when the LED is illuminated. Indicates the unit is off when LED is not lit.

4**Mode Selector Switch Legend**

Indicates the operation of the 3 Position Mode Selector Switch as described in (2).

Operating Pointers

Remember to check attenuation of the fiber optic cable. The system will only operate properly if these specifications fall within the range of the system's loss budget.

Troubleshooting

Multimode fiber optic cable contains an optical fiber with a light carrying "core" that is only .0025 inches (62.5 microns) in diameter. Single mode fiber optic cable has an even smaller "core," only .00032 to .0004 inches (8-10 microns). This is smaller than a human hair! Therefore, any minute particles of dirt or dust can easily block the fiber from accepting or radiating light. To prevent this from happening, always use the provided dust caps when ever optical connectors are exposed to air. It is also a good idea to gently clean the tip of an optical connector with a lint-free cloth moistened with alcohol whenever dust is suspected.

The status of the LED's should provide the first clue as to the origin of any operational failure. If these are off, it usually means that the battery has failed in the unit.

If, after reviewing the above possibilities, the system is still not operating, please contact the Customer Service Department for further assistance. If you suspect your problem is caused by the optics or the fiber optic cable, and you have an optical power meter, please take the appropriate measurements prior to contacting support.

Maintenance and Repairs

The FiberLink 6656 Series has been manufactured using the latest semiconductor devices and techniques that electronic technology has to offer. They have been designed for long, reliable and trouble-free service and are not normally field repairable.

Should difficulty be encountered, Artel Video Systems maintains a complete service facility to render accurate, timely and reliable service of all products.

The only maintenance that can be provided by the user is to ascertain that optical connectors are free of dust or dirt that could interfere with light transmission and that connections are secure and accurate.

All other questions or comments should be directed to our Customer Service Department. It should be noted that many "problems" can easily be solved by a simple telephone call.

Proven Products, Unrivalled Service, and Great Support



- High performance plug and play products
- Stand alone and card cage versions available
- Solutions for most video, audio, and data formats
- Multimode and single mode versions
- Designed and manufactured in the USA
- Training and installation support available
- 24x7x365 technical support available



Artel Video Systems Corp.
5B Lyberty Way,
Westford, MA 01886 USA
T: 978-263-5775
F: 978-263-9755
sales@artel.com
customercare@artel.com
www.artel.com

All specifications subject to
change without notice. ©2016
Updated 07/31/2016
CS200-129699-00_E